



"TANK STEERING"



4/6 Channel Transmitter

Uses two channels of Tx to control each motor from its own stick. Differential motor speed is applied with your thumbs, if required, and is independent of rudder commands. Alternatively electronic mixing from your Tx may be possible (see R/C system manual). If fitted, the Bow Thruster is independent and controlled from LH stick.



19 Carisbrooke Drive
Nottingham NG3 5DS
United Kingdom
+44(0)115 9607951
www.action-electronics.co.uk

Voltage to suit main motors